

Electrical variable gripper EVG 55

Assembly and Operating Manual



Imprint

Copyright:

This manual remains the copyrighted property of SCHUNK GmbH & Co. KG. It is solely supplied to our customers and operators of our products and forms part of the product. This documentation may not be duplicated or made accessible to third parties, in particular competitive companies, without our prior permission.

Technical changes:

We reserve the right to make alterations for the purpose of technical improvement.

Document number: 0389066

Edition: 05.01 | 19/08/2016 | en

© SCHUNK GmbH & Co. KG

All rights reserved.

Dear customer,

congratulations on choosing a SCHUNK product. By choosing SCHUNK, you have opted for the highest precision, top quality and best service.

You are going to increase the process reliability of your production and achieve best machining results – to the customer's complete satisfaction.

SCHUNK products are inspiring.

Our detailed assembly and operation manual will support you.

Do you have further questions? You may contact us at any time – even after purchase.

Kindest Regards

Yours SCHUNK GmbH & Co. KG

Spann- und Greiftechnik

Bahnhofstr. 106 – 134

D-74348 Lauffen/Neckar

Tel. +49-7133-103-0

Fax +49-7133-103-2399

info@de.schunk.com

www.schunk.com



Reg. No. 003496 QM08



Reg. No. 003496 QM08

Table of Contents

1	General	6
1.1	About this manual	6
1.1.1	Presentation of Warning Labels	6
1.1.2	Applicable documents.....	7
1.1.3	Sizes	7
1.2	Warranty	7
1.3	Scope of delivery.....	7
1.4	Accessory.....	7
2	Basic safety notes	8
2.1	Intended use	8
2.2	Not intended use	8
2.3	Constructional changes	8
2.4	Spare parts	8
2.5	Gripper fingers	9
2.6	Ambient conditions and operating conditions	9
2.6.1	Electromagnetic compatibility.....	9
2.6.2	Environmental conditions.....	11
2.7	Personnel qualification.....	13
2.8	Personal protective equipment.....	14
2.9	Notes on safe operation.....	14
2.10	Transport.....	15
2.11	Malfunctions	15
2.12	Disposal	15
2.13	Fundamental dangers.....	16
2.13.1	Protection during handling and assembly	16
2.13.2	Protection during commissioning and operation	17
2.13.3	Protection against dangerous movements	17
2.13.4	Protection against electric shock	18
2.13.5	Protection against magnetic and electromagnetic fields.....	19
2.14	Notes on particular risks	20
3	Technical data.....	22
3.1	Basic data	22
3.2	Diagrams.....	23
3.3	Motor data	24
4	Design and description	25
4.1	Configuration	25

4.2	Operation principle.....	26
5	Assembly and installation.....	27
5.1	Mechanical connection	27
5.2	Special connection dimensions	29
5.3	Electrical connection	31
5.3.1	Connection principle	31
5.3.2	EMV fitting of connection cable to the gripper.....	32
5.4	Electrical connection of the module to the MCS-06 controller	34
5.4.1	Scope of delivery of MCS-06 controller	35
5.4.2	Technical data of the MCS-06 controller	35
5.4.3	Configuration and description of the MCS-06 controller	36
5.4.4	Procedure and requirements	38
5.4.5	Configuration of terminal strip X1 of the MCS-06 controller	39
5.4.6	Configuration of terminal strip X2 of the MCS-06 controller	40
5.4.7	Configuration of terminal strip X3 of the MCS-06 controller	41
5.4.8	Configuration of terminal strip X4 of the MCS-06 controller	43
5.4.9	Pin assignment of communication interfaces	43
5.5	Connecting ground cable	47
5.6	Function and handling.....	48
5.7	Commissioning and system integration via the SCHUNK MCS-06 controller	49
5.7.1	System structure	49
5.7.2	SCHUNK Motion protocol	50
5.7.3	Important commands	51
6	Troubleshooting	54
6.1	Behavior in case of product malfunctions	54
6.1.1	Gripper does not move	54
6.1.2	Gripping force decreases / gripper opens and closes abruptly	54
6.1.3	Gripper does not travel through the entire stroke	54
6.2	Motor does not turn.....	54
6.3	Behavior in case of malfunctions of the MCS-06 SCHUNK controller	55
6.3.1	LEDs on Controller Do Not Light Up.....	55
6.3.2	POW LED (Green) Does Not Light Up.....	55
6.3.3	RDY LED (Green) Does Not Light Up	55
6.3.4	ERR LED (Red) Flashing.....	55
6.3.5	Product stops abruptly.....	56
6.3.6	Module Does Not Move/Respond	56
7	Maintenance.....	57

7.1	Maintenance intervals.....	57
7.2	Measures for preserving the gripper's function.....	57
7.3	Cleaning.....	58
7.3.1	Gripper	58
7.3.2	Controller	58
7.4	Lubricants/lubrication points.....	58
7.5	Disassembly and assembly.....	59
8	Translation of original declaration of incorporation.....	60

1 General

1.1 About this manual

This manual contains important information for a safe and appropriate use of the product.

This manual is an integral part of the product and must be kept accessible for the personnel at all times.

Before starting work, the personnel must have read and understood this operating manual. Prerequisite for safe working is the observance of all safety instructions in this manual.

Illustrations in this manual are provided for basic understanding and may differ from the actual product design.

In addition to these instructions, the documents listed under [\(☞ 1.1.2, Page 7\)](#) are applicable.

1.1.1 Presentation of Warning Labels

To make risks clear, the following signal words and symbols are used for safety notes.

	 DANGER Danger for persons! Non-observance will inevitably cause irreversible injury or death.
	 WARNING Dangers for persons! Non-observance can lead to irreversible injury and even death.
	 CAUTION Dangers for persons! Non-observance can cause minor injuries.
	NOTICE Material damage! Information about avoiding material damage.

1.1.2 Applicable documents

- General terms of business *
- Catalog data sheet of the purchased product *
- Assembly and Operating manuals of the accessories *
- Software Manual – Motion Control *

The documents marked with an asterisk (*) can be downloaded on our homepage **www.schunk.com**.

1.1.3 Sizes

This operating manual applies to the following sizes:

- EVG - 40
- EVG - 100

1.2 Warranty

If the product is used as intended, the warranty is valid for 24 months from the ex-works delivery date under the following conditions:

- Observe the ambient conditions and operating conditions ([👉 2.6, Page 9](#))
- Observe the specified maintenance and lubrication intervals ([👉 7, Page 57](#))

Parts touching the workpiece and wearing parts are not included in the warranty.

1.3 Scope of delivery

The scope of delivery includes

- 2-Finger ParallelgreiferEVG in the ordered model
- USB to RS232 converter inclusive driver CD
- Accessory pack
- EVG - cable length 3m 4mm x 1mm

1.4 Accessory

The following accessories, which must be ordered separately, are required for the product:

- Controller (e.g. SCHUNK MCS-06)

A wide range of accessories are available for this product

For information about which accessories can be used with the appropriate product version see catalog.

2 Basic safety notes

2.1 Intended use

The product is designed exclusively for gripping and temporarily holding workpieces or objects.

- The product may only be used within the scope of its technical data, ([☞ 3, Page 22](#)).
- The product is intended for installation in a machine/system. The applicable guidelines must be observed and complied with.
- The product is intended for industrial use.
- Appropriate use of the product includes compliance with all instructions in this manual.

2.2 Not intended use

It is not intended use if the product is used, for example, as a pressing tool, stamping tool, lifting gear, guide for tools, cutting tool, clamping device or a drilling tool.

- Any utilization that exceeds or differs from the appropriate use is regarded as misuse.

2.3 Constructional changes

Making constructional changes

Attachments and modifications, constructional changes and subsequent work, e.g. additional threads, drill holes and safety devices may impair the operation and safety or damage the product.

- Constructional changes may only be done with SCHUNK's permission.

2.4 Spare parts

Use of unauthorised spare parts

Using unauthorised spare parts can endanger personnel and damage the product or cause it to malfunction.

- Use only original spare parts or spares authorised by Schunk.

2.5 Gripper fingers

Requirements for the gripper fingers

Stored energy within the product creates the risk of serious injuries and significant property damage.

- Arrange the gripper fingers in a way that the product reaches either the position "open" or "closed" in a de-energized state.
- Only exchange the gripper fingers when no residual energy remains in the product.

2.6 Ambient conditions and operating conditions

Required ambient conditions and operating conditions

Incorrect ambient and operating conditions can make the product unsafe, leading to the risk of serious injuries, considerable material damage and/or a significant reduction to the product's life span.

- Make sure that the product is used only in the context of its defined application parameters, ([🔗 3, Page 22](#)).
- Ensure that the product is protected against sprayed water, vapors, contamination, and EMC influences during operation. Exceptions are products that are designed especially for contaminated environments.

2.6.1 Electromagnetic compatibility

The product meets the requirements of the EMC act of the inner-European market, among other requirements. The product has passed the EMC test as per the following standards:

Standard	Title
EN 61000-6-2 (2006)	EMC: Generic standard – Interference immunity in industrial environments
EN 61000-6-3 (2011)	EMC: Generic standards - emitted interference for living area, business and commercial areas and small businesses

The product must be installed using interference-free cables and in a way that meets EMC requirements in order to ensure interference-free operation.

Interference variables The electromagnetic compability with pulse-shaped inference variables has been verified and confirmed according to the following standards:

Standard	Title
EN 61000-4-2 (2008)	Test and measurement procedures - Testing the interference immunity to discharging of static electricity
EN 61000-4-4 (2008)	Test and measurements procedures - Testing the interference immunity to fast transient electric interference variables/burst
EN 61000-4-5 (2014)	Test and measurement procedures - Testing the interference immunity to surge voltages

Sinusoidal interference variables:

The electromagnetic compability with sinusoidal interference variables has been verified and confirmed according to the following standards:

Standard	Title
EN 61000-4-3 (2011)	Test and measurement procedures - Testing the interference immunity to electromagnetic high frequency fields
EN 61000-4-6 (2014)	Test and measurement procedures - interference immunity to conducted interference variables induced by high frequency fields

Emission of radio interference The emission of radio interference has been verified and confirmed according to the following standards:

Standard	Title
EN 61000-6-3 (2011)	EMC: Generic standards - emitted interference for living area, business and commercial areas and small businesses

The emitted interference of electromagnetic fields (limit class A, group 1, measured with 10 m distance) has been tested according to the following standards:

Standard	Title
EN 55011 (2009)	Industrial, scientific and medical devices - radio interference - limits and measurement procedures

2.6.2 Environmental conditions

Requirements for transport and storage The following information applies if the product is transported and stored in the original package.

Mechanical Environmental Conditions Standard: IEC 60721-3-2 (1997-02) Title: Classification of environmental conditions – Part 3: Classification of groups of environmental parameters and their severities, Section 2: Transportation. Class 2M3 applies.

Climatic Environmental Conditions Standard: IEC 60721-3-2 (version 1997-02) Title: Classification of environmental conditions – Part 3: Classification of groups of environmental parameters and their severities, Section 2: Transportation. Class 2K4 applies.

The aforementioned standards result in the following parameters for the essential environmental conditions:

Standard	Title
EN 60068-2-1	Test procedure - test A: cold
EN 60068-2-2	Test procedure - test B: dry heat
EN 60068-2-13	Tests - test group M: low air pressure
EN 60068-2-14	Test procedure - test N: temperature change
IEC 60068-2-32	Tests - Test ed: Free fal

Requirements during operation The following overview shows the permissible environmental conditions for the product.

Mechanical Environmental Conditions Standard: IEC 60721-3-3 (1995-09) Title: Classification of environmental conditions – Part 3: Classification of groups of environmental parameters and their severities, Section 3: Stationary use at weather-protected locations. Class 3M7 applies.

Climatic Environmental Conditions Standard: IEC 60721-3-3 (1995-09) Title: Classification of environmental conditions – Part 3: Classification of groups of environmental parameters and their severities, Section 3: Stationary use at weather-protected locations. Class 3K3 applies

The product has been tested for the essential environmental conditions according to the following standards:

Standard	Title
EN 60068-2-1	Test procedure - test A: cold
EN 60068-2-2	Test procedure - test B: dry heat
EN 60068-2-30	Test procedure - test Db: humid heat, cyclical (12 + 12 hours)

The product may only be used in the following locations if additional measures are taken:

- In locations with a high level of ionizing radiation
- In locations with difficult operating conditions, e.g., due to caustic fumes, gases, oils or chemicals
- In facilities requiring special monitoring, e.g., in particularly at-risk areas

The product must also not be used in potentially explosive zones. If the product is subjected to unacceptably large impacts or vibrations, suitable measures must be taken to reduce the amplitude or acceleration of such disturbances. Vibration-damping or vibration-absorbing systems are to be used in such cases.

Testing environmental conditions

Tests regarding mechanical environmental conditions

The product has been tested with respect to mechanical environmental conditions according to the following standards:

Standard	Title
EN 60068-2-6 (2008-10)	Test procedure - test Fc: swinging (sinusoidal)
EN 60068-2-27 (2010-02)	Test procedure - test Ea and guideline: shocking

2.7 Personnel qualification

Inadequate qualifications of the personnel

If the personnel working with the product is not sufficiently qualified, the result may be serious injuries and significant property damage.

- All work may only be performed by qualified personnel.
- Before working with the product, the personnel must have read and understood the complete assembly and operating manual.
- Observe the national safety regulations and rules and general safety instructions.

The following personal qualifications are necessary for the various activities related to the product:

Trained electrician	Due to their technical training, knowledge and experience, trained electricians are able to work on electrical systems, recognize and avoid possible dangers and know the relevant standards and regulations.
Pneumatics specialist	Pneumatics specialists have been trained for this particular area of responsibility and know the relevant standards and regulations.
Hydraulic specialist	Hydraulic specialists have been trained for this particular area of responsibility and knows the relevant standards and regulations.
Qualified personnel	Due to its technical training, knowledge and experience, qualified personnel is able to perform the delegated tasks, recognize and avoid possible dangers and knows the relevant standards and regulations.
Instructed person	Instructed persons were instructed by the operator about the delegated tasks and possible dangers due to improper behaviour.
Service personnel of the manufacturer	Due to its technical training, knowledge and experience, service personnel of the manufacturer is able to perform the delegated tasks and to recognize and avoid possible dangers.

2.8 Personal protective equipment

Using personal protective equipment

Not wearing personal protective equipment while working with the product, may result in dangers that impact the personnel's safety and health.

- While working with the product, observe the health and safety regulations and wear the required personal safety equipment.
- Observe the valid safety and accident prevention regulations.
- In case of sharp edges and corners and rough surfaces, wear protection gloves.
- In case of hot surfaces, wear heat-resistant protection gloves.
- When dealing with hazardous substances, wear protection gloves and goggles.
- In case of moving parts, wear tight protection clothes.

2.9 Notes on safe operation

Incorrect manner of working by personnel

Working in an incorrect manner may impair the product's safety and cause serious injuries and considerable material damage.

- Avoid any manner of working that may interfere with the function and operational safety of the product.
- Use the product as intended.
- Observe the safety notes and assembly instructions.
- Do not expose the product to any corrosive media.
- Rectify malfunctions as soon as they occur.
- Observe the care and maintenance instructions.
- Observe the current safety, accident prevention and environmental protection regulations regarding the product's application field.

2.10 Transport

Handling during transport

Incorrect handling during transport may impair the product's safety and cause serious injuries and considerable material damage.

- When handling heavy weights, use lifting equipment to lift the product and transport it by appropriate means.
- Secure the product against falling during transportation and handling.
- Stand clear of suspended loads.

2.11 Malfunctions

Behavior in case of malfunctions

- Immediately remove the product from operation and report the malfunction to the responsible departments/persons.
- Order appropriately trained personnel to rectify the malfunction.
- Do not recommission the product until the malfunction has been rectified.
- Test the product after a malfunction to establish whether it still functions properly and no increased risks have arisen.

2.12 Disposal

Handling of disposal

The incorrect handling of disposal may impair the product's safety and cause serious injuries as well as considerable material and environmental harm.

- Follow local regulations on dispatching product components for recycling or proper disposal.

2.13 Fundamental dangers

General

- Observe safety distances.
- Never deactivate safety installations.
- Install the provided protective product in the danger zone before switching on the product.
- Remove energy supplies before the installation, modification, maintenance or adjustment work. Make sure that no residual energy is remaining in the system.
- Do not move parts by hand while the energy supply is connected.
- Do not reach into the open mechanism or movement area of the product during operation.

2.13.1 Protection during handling and assembly

Incorrect handling and assembly

Incorrect handling and assembly may impair the product's safety and cause serious injuries and considerable material damage.

- Have all work carried out by appropriately qualified personnel.
- For all work, secure the product against accidental operation.
- Observe the relevant accident prevention rules.
- Use suitable assembly and transport equipment and take precautions to prevent jamming and crushing.

Incorrect lifting of loads

Falling loads may cause serious injuries and even death.

- Stand clear of suspended loads and do not step into their swivelling range.
- Never move loads without supervision.
- Do not leave suspended loads unattended.

2.13.2 Protection during commissioning and operation

Falling or violently ejected components

Falling and violently ejected components can cause serious injuries and even death.

- The danger zone must be cordoned off by a protective barrier.
- Never step into the danger zone during operation.

2.13.3 Protection against dangerous movements

Unexpected movements

Residual energy in the system may cause serious injuries while working with the product.

- Switch off the energy supply and ensure that no residual energy remains.
- The faulty actuation of connected drives may cause dangerous movements.
- Operating mistakes, faulty parameterization during commissioning or software errors may trigger dangerous movements.
- Never rely solely on the response of the monitoring function to avert danger. Until the installed monitors become effective, it must be assumed that the drive movement is faulty, with its action being dependent on the control unit and the current operating condition of the drive. Perform maintenance work, modifications, and attachments outside the danger zone defined by the movement range.
- To avoid accidents and/or material damage, human access to the movement range of the machine must be restricted. Restrict unintentional access by persons to this range e.g. via a protective cover, protective fence or photoelectric barrier. The protective cover and protective fence must be rigid enough to withstand the maximum possible movement energy. EMERGENCY STOP switches must be easily and quickly accessible. Check the function of the EMERGENCY STOP before starting up the machine or system. If this protective equipment is not working properly, prevent the operation of the machine.

2.13.4 Protection against electric shock

Work on electric equipment

Touching live parts may cause death.

- Work on electrical installations must be performed only by electricians in accordance with the electrical regulations.
- Observe the general installation and safety regulations concerning work on high-voltage systems.
- Lay electrical cables correctly, e.g. in a cable duct or cable protector. Observe standards.
- Before connecting or disconnecting electric cables, switch off power supply and make sure the lines are dead. Secure power supply against reactivation.
- Before working on the product, disconnect it from the line power and wait for at least 15 minutes to allow dangerous voltage charges to dissipate (capacitor charge). Check that the device is deenergized before you start working.
- Before switching on the product, check if the protective conductor on all electrical components has been installed correctly according to the connection diagram.
- Check if covers and safety equipment preventing contact with live components have been installed.
- Do not touch the product's connecting elements while the energy supply is switched on.

Possible electrostatic energy

Components or assembly groups may become electrostatically charged. When the electrostatic charge is touched, the discharge may trigger a shock reaction leading to injuries.

- The operator must ensure that all components and assembly groups are included in the local equipotential bonding in accordance with the applicable regulations.
- While paying particular attention to the actual conditions of the working environment, the equipotential bonding must be implemented by a specialist electrician according to the applicable regulations.
- The effectiveness of the equipotential bonding must be verified by executing regular safety measurements.

2.13.5 Protection against magnetic and electromagnetic fields

Work in areas with magnetic and electromagnetic fields

Magnetic and electromagnetic fields can lead to serious injuries.

- Persons with pace-makers, metal implants, metal shards or hearing aids require the consent of a physician before entering areas in which components of the electric drive and control systems are mounted, started up and operated.
- Persons with pace-makers, metal implants, metal shards or hearing aids required the consent of a physician before entering areas in which motor parts with permanent magnets are stored, repaired or assembled.
- Do not operate high-frequency or radio products in the proximity of electric components of the drive system and their feed lines.

If the use of such devices is necessary:

When starting up the electric drive and control system, check the machine or system for possible failures when such systems are used at different intervals and in different states of the control system. A special additional EMC test may be necessary if the system has a high risk potential.

2.14 Notes on particular risks

	 DANGER Danger from electric voltage! Touching live parts may result in death. • Switch off the power supply before any assembly, adjustment or maintenance work and secure against being switched on again. • Only qualified electricians should perform electrical installations. • Check if de-energized, ground it and hot-wire. • Cover live parts.
	 DANGER Risk of fatal injury from suspended loads! Falling loads can cause serious injuries and even death. • Stand clear of suspended loads and do not step within their swiveling range. • Never move loads without supervision. • Do not leave suspended loads unattended. • Wear suitable protective equipment.
	 WARNING Risk of injury from objects falling and being ejected! Falling and ejected objects during operation can lead to serious injury or death. • The danger zone must be cordoned off by a protective barrier.



! WARNING

Risk of injury from uncontrolled movements!

If the energy supply is switched on or residual energy remains in the system, parts may move unexpectedly and cause serious injuries.

- Switch off energy supply.
- Make sure there is no residual energy in the system



! WARNING

Risk of injury due to squeezing and bumping!

Moving the base jaws and breaking or loosening the gripper fingers may cause serious injuries.

- Do not reach into the product's open mechanical system or movement range.



! WARNING

Risk of injury from sharp edges and corners!

Sharp edges and corners can cause cuts.

- Use suitable protective equipment.



! WARNING

Risk of injury from objects falling during energy supply failure!

Electronic devices are not fail-safe. In case of an energy supply failure, the gripping force decreases. As a consequence, it cannot be guaranteed that the workpiece is held safely.

- In case of an energy supply failure, it is the user's responsibility to revert the drive into a safe state.

3 Technical data


3.1 Basic data

Size	EVG	
	55 stroke 40	55 stroke 100
Mechanical operating data		
Weight [kg]	0.79	1.1
Noise emission [dB(A)]	≤ 70	
IP Code	20	
Ambient temperature [°C]		
Min.	+5	
Max.	+55	
Stroke per jaw [mm]	20	50
Min. gripping force [N]	5	
Max. gripping force [N] at max. current	24	57
Max. speed [mm/s]	300	400
Max. acceleration [mm/s²]	10000	
Repeatability [mm] ***	±0.05	
Max. permissible finger length [mm]	125	
Electrical operating data		
Nominal voltage [VDC] MCS-06	24	
Nominal power current [A]	4	5
Max. current [A]	8	
Control electronics		
Interface		
RS232	X	X
CAN bus	X	X
Profibus DP	X	X
Power supply [VDC] (Logic)	24	
Nominal power current [A] (Logic)	0.5	
Sensor system	Encoder	


- * Gripping force is the arithmetical sum of the single forces arising at the gripper jaws in a distance of $P=50\text{ mm}$ for $l=8\text{ Aeff}$, of 6 mm pre-positioning and the max. velocity. Observe the temperature behavior in relation to the time of the applied current
([3.3, Page 24](#)).
- ** Values for friction coefficient $\mu = 0.1$ and safety factor $v = 2$. In case of form-fit gripping, the values can be increased.
- *** Scattering of end positions for 100 consecutive strokes.

More technical data are included in the catalog data sheet. Whichever is the latest version.

3.2 Diagrams



Stroke diagrams



Gripping force diagrams

3.3 Motor data

Reference value	EVG 55 Stroke 40	EVG 55 Hub 100
Terminal voltage U_{kl} [V]	24	
Torque constant K_t [Ncm/A]	1.3	3.8
Ambient temperature θ_u [°C]	40	
Maximal winding temperature θ_{max} [°C]	140	
Thermal transfer resistance R_{th} [K/W]	4.5	3.25
Maximal torque M_{max} [Ncm]	23.5	72.4
Maximal current I_{max} [Aeff]	16.0	
Permanent standstill torque M_o [Ncm]	5.9	18.0
Permanent standstill current i_o [Aeff]	4.0	3.9
Idle speed n_o [min-1]	19100	6200
Nominal torque M_n [Ncm]	5.0	16.3
Nominal current I_n [Aeff]	3.6	3.7
Nominal torque n_n [min-1]	15900	5100
Terminal inductance R_{tt} [Ω]	0.5 ±7%	0.6 ±7%
Terminal inductance L_{tt} [mH]		0.4 ±20%
Electrical time constant τ_e [ms]	0.4 ±27%	0.7 ±27%

The tolerances of M, I, n may be around 10%. All temperatures correspond to isolation class F.

Mmax is limited by the maximal current.

4 Design and description

4.1 Configuration

The gripper base jaws are designed in such a way that different types of fingers for parallel grippers can be attached to them. A controller supplies the gripper with voltage.

- For an optimal operation, the SCHUNK MCS-06 controller is recommended.


The module is equipped with a brushless direct current servo motor with bevel gear and toothed belt.

The unit is intended for gripping, holding and loosening workpieces.

The module has functions for monitoring end positions, voltage, current and temperature. The module shuts itself down if the permitted values are exceeded.

All parameters like velocity, stroke, position or motor current are transmitted to an external controller via the corresponding interface (RS232, CAN Bus, Profibus).

4.2 Operation principle



Operation principle external logic

The actuator (in this case DC motor) is controlled by the external logic (controller). The superior control (master) transfers the required parameters to the external logic (controller).

The module performs a movement. Its position is constantly monitored. Sensors transfer the required parameters back to the external logic.

The following parameters can be transferred from the controller (master) to the internal logic:

- Current I
- Velocity v
- Acceleration a
- Position (distance between base jaws)

5 Assembly and installation

5.1 Mechanical connection

	 WARNING
	Risk of injury from uncontrolled movements! If the energy supply is switched on or residual energy remains in the system, parts may move unexpectedly and cause serious injuries. • Switch off energy supply. • Make sure there is no residual energy in the system


Levelness of the mounting surface The values apply to the whole mounting surface to which the product is mounted .

Requirements for levelness of the mounting surface (Dimensions in mm)

Diameter	Permissible unevenness
< 100	< 0.02
> 100	< 0.05

- Use suitable connecting elements (adapter plate) to connect the module to the machine/system.
- Observe the permissible screw-in depth.

Mounting The gripper can be fastened and fixed via the lateral threads with centering. Another possibility is the adaption via a L-shaped adapter plate with ISO 9409-1-A50 flange:




Assembly possibilities

1	L-shaped adapter plate with flange according to ISO 9409-1-A50
2	Mounting screws DIN EN ISO 4762 and centering sleeve 6x5.35

NOTE

Optionally the module can be mounted to the flat change head (FWK) with flat change system (FWS):




Mounting at the FWS

1	Flat change head with adapter	2	adapter plate
---	-------------------------------	---	---------------


5.2 Special connection dimensions

The gripper EVG can be screwed to the lateral M4 mounting threads. For fastening the top jaws, there are respectively two M3 mounting threads at the base jaws:



Connection dimensions EVG55 stroke 40

1	Gripper connection	72	Fit for centering sleeves
2	Finger connection	80	Depth of the centering bore in the counterpart
17	M16x1,5 for cable connection		



Connection dimensions EVG55 stroke 100

1	Gripper connection	72	Fit for centering sleeves
2	Finger connection	80	Depth of the centering bore in the counterpart
17	M16x1,5 for cable connection		

5.3 Electrical connection

NOTE

The cable color throughout this chapter refers to the use of a SCHUNK connection cable.



NOTICE

Danger of short circuit!


Damage of circuit board possible!

- Observe configuration of the terminals.
- Electrical connection may only be performed by qualified personnel.

5.3.1 Connection principle

The controller supplied the gripper with voltage.


- The gripper must be connected to the controller.




Connection principle

5.3.2 EMV fitting of connection cable to the gripper

Signal and power lines of the controller (MCS-06) are connected to the gripper's connection board.



- 1 Loosen countersunk screws (4) and remove the cover (2).
- 2 Pull the connection cable through the EMV-fitting (1).
- 3 Isolate the connection cable and the single conductors (ca. 90 mm from the outer sheath of the MCS-06 connection cable and the single conductors ca. 5 mm, corresponding to the spring terminals).
- 4 Fold the outer shielding over the sheath of the connection cable and fix the shrink hose (☞ figure below). The shielding remains visible at the end of the sheath.
- 5 Connect the connection cable directly to the connection board (3). Extending the connection board is not necessary. (☞ Fig. and tab. connection board with terminals and configuration of terminals).




EMC-fitting



NOTICE

Damage of circuit board possible!

- Electrical connection may only be performed by qualified personnel.
- Never remove the adapter plate from the gripper.



Connection board with terminals and configuration of terminals

Item	Connection board EVG55	Pin	Function	SCHUNK cable color
1	Terminal strip X5	1	Brake -	Brown (0,34mm ²)
		2	Brake +	White (0,34mm ²)
		3	Hall sensor 1	Yellow
		4	Hall sensor 2	Pink
		5	Hall sensor 3	Grey
		6	Encoder track A	Black
		7	Encoder track B	White
		8	Encoder track C	Copper
		9	Encoder track A\	Violet
		10	Encoder track B\	Brown
		11	Encoder track C\	Orange
		12	GND	Blue
		13	+5V	Red
2	Bushing X8	1	-	
		2	-	
		3	Encoder track C\	
		4	Encoder track B\	
		5	Encoder track A\	
		6	Encoder track C	
		7	Encoder track B	

Item	Connection board EVG55	Pin	Function	SCHUNK cable color	
		8	Encoder track A		
		9	GND		
		10	+5V		
		11	Hall sensor 3		
		12	Hall sensor 2		
		13	Hall sensor 1		
		14	GND		
		15	+5V		
		16	-		
		17	-		
		18	-		
		19	-		
		20	-		
3	Bushing X23	1	Brake +		
		2	Brake -		
4	Terminal strip X7	1	Shielding	Grey	Lines of the external controller
		2	Motor phase W	Black	
5	Terminal strip X9	1	Motor phase U	Red	Lines of the motor in the grip- per
		2	Motor phase V	White	
6	Terminal strip X10	1	Motor phase U	Red	Lines of the external controller
		2	Motor phase V	White	
7	Terminal strip X6	1	Shielding	Grey	Lines of the motor in the grip- per
		2	Motor phase W	Black	

5.4 Electrical connection of the module to the MCS-06 controller

NOTE

The cable color throughout this chapter refers to the use of a SCHUNK connection cable.

5.4.1 Scope of delivery of MCS-06 controller

The MCS-06 is an accessory and can be ordered separately.

The scope of delivery includes

- MCS-06 controller
- DVD

Content of DVD:


- Motion Tool SCHUNK (MTS) (configuration and commissioning tool)
- Operating manual in PDF format
- Software manual Motion Tool SCHUNK in PDF format
- Software module for Siemens S7300/400

5.4.2 Technical data of the MCS-06 controller

Type	MCS-06
Logic voltage supply at controller [VDC]	24
Current consumption of logic [A]	0.5
Nominal current for controller [A]	6
Power supply [VDC]	24
Weight [kg]	0.45
Interfaces = communication type (data rate)	RS232 (9600 baud) Profibus DP (auto-detect) CAN
Control types	Current control Velocity control Positioning control
Technical data of outputs	
Type of output	Opto-isolator
U_{out} [V]	>12
Ground potential	GND
Max. power output [mA]	>3
Short-circuit-proof	yes
Protected against polarity reversal	yes
Galvanically isolated	yes
Technical data of inputs	


Type	MCS-06
Switching threshold ,High' [V]	>3
Switching threshold ,Low' [V]	<0,5
Current consumption of logic [A]	<5
Protected against polarity reversal	yes
Galvanically isolated	yes

5.4.3 Configuration and description of the MCS-06 controller



Configuration of the MCS-06 controller

1	Connection Profibus	2	Connection CAN
3	Connection RS232	4	Terminal strip X1 (5.4.5, Page 39)
5	Display - LED for POW (indicates if power supply is available)	6	Display - LED for RDY (indicates communication readiness)
7	Display - LED for ERR (indicates occurring errors)	8	Terminal strip X2 (5.4.6, Page 40)
9	Terminal strip X3 (5.4.7, Page 41)	10	Terminal strip X4 (5.4.8, Page 43)



Dimensions of the controller

The controller is fastened with a metal base latch to a support rail (according to EN 50022).

DEFAULT function Reset the module via the SCHUNK controller.

NOTE

For more information on the DEFAULT values, see the Motion-ToolSchunk.pdf on the controller's DVD.

Perform the following steps:

- 1 Switch off the logic voltage supply at the controller.
- 2 Set a jumper between pin 9 (GND) and pin 14 (default) on terminal strip X3.
- 3 Turn on the logic voltage supply at the controller.
- 4 Wait approximately 10 seconds.
- 5 Switch off the logic voltage supply.
- 6 Remove the jumper.

DEFAULT values Now the unit is reset:

- Module address = 12
- Communication = RS232
- Data rate = 9,600 baud

Loading new firmware on the module The new firmware can be loaded on the module via the Motion Tool Schunk software (MTS) (on the supplied DVD) under "Module" - "Update firmware".

NOTE

For further information  MotionToolSchunk.pdf document on the DVD.


5.4.4 Procedure and requirements

	 DANGER	
	Danger due to faulty connection. • Observe the pin assignment of the connecting terminals. • Make sure that all components are grounded correctly.	
Voltage supply requirements	Power supply (MCS-06)	24 V DC
	Voltage supply of motor (gripper)	24 V DC (+ 10% / - 4%)
	Voltage supply of logic	24 V DC (up to 36 V DC) ripple smaller than 150 mVSS; switching peak smaller than 240 mVSS
	Connection value	Number of modules x nominal module current x 1.2

5.4.5 Configuration of terminal strip X1 of the MCS-06 controller

The strands with 1.0 mm² cross-section are required.

Terminal strip X1 Terminal strip X1 serves for connecting the controller's motor phases:



Terminal strip X1

Position of terminal strip ([👉 5.4.3, Page 36](#))


Configuration of the pins of terminal strip X1

Pin	Function	Cable color
1	Motor phase U	Red
2	Motor phase V	White
3	Motor phase W	Black
4	Shielding	Grey

5.4.6 Configuration of terminal strip X2 of the MCS-06 controller

The strands with 0.15 mm² cross-section are required.

Terminal strip X2 The terminal strip X2 serves for connecting the encoder, Hall sensors and resolver:



Terminal strip X2

Position of terminal strips ([5.4.3, Page 36](#))


Configuration of the pins of terminal strip X2

Pin	Function	Cable color (diff. encoder)
1	Resolver signal reference +	-
2	Resolver signal COSINUS +	-
3	Resolver signal COSINUS -	-
4	Resolver signal SINUS +	-
5	Resolver signal SINUS -	-
6	Encoder track A (or Adiff)	Black
7	Encoder track B (or Bdiff)	White
8	Encoder track C (or Adiff\)	Violet
9	+5V for encoder and Hall sensor	Red
10	GND for encoder and Hall sensor	Blue
11	Hall sensor 1	Yellow
12	Hall sensor 2	Pink
13	Hall sensor 3	Grey
14	Brake -	Brown (0,34mm ²)
15	Brake +	White (0,34mm ²)
16	Resolver signal reference -	-

5.4.7 Configuration of terminal strip X3 of the MCS-06 controller

The strands with 0.15 mm² cross-section are required.

Terminal strip X3 Terminal strip X3 serves for connecting digital inputs and outputs, the encoder and the voltage supply +24 V DC of the logic:



Terminal strip X3

Position of terminal strips ([5.4.3, Page 36](#))

Configuration of the pins of terminal strip X3

Pin	Function	Cable color (diff. encoder)
1	Encoder track Bdiff\	Brown
2	Encoder track Cdiff	Copper
3	Encoder track Cdiff\	Orange
4	Digital output 1	-
5	Digital output 2	-
6	Digital output 3	-
7	Digital output 4	-
8	+24V logic supply	-
9	GND logic supply	-
10	Digital input 4	-
11	Digital input 3	-
12	Digital input 2	-
13	Digital input 1	-
14	Default	-

Configuration of in- and outputs

Inputs and outputs of terminal strip X3

Pin	Designation	Application: Program	Application: Normal
13	DI1	Release / External reference switch (as of Firmware 1.20)	Digital input (IN0)
12	DI2	Sentence selection	Digital input (IN1)
11	DI3	Sentence selection	Digital input (IN2)
10	DI4	Sentence selection	Digital input (IN3)
4	DO1	Reference (low active)	Digital output (OUT0)
5	DO2	Error message (low active)	Digital output (OUT1)
6	DO3	Depending on configuration (low active)  See table below	Digital output (OUT2)
7	DO4	Movement finished (low active)	Digital output (OUT3)

Switching possibilities of the output DO3 via Motion Tool Schunk (as of Firmware V1.22)


Setting	Description
Normal	Digital output via CMD_DIO switchable
Status + movement	OUT2 reports, if the module is moving.
Status + position achieved	OUT2 reports, if the module achieved a position.
Status + brake	OUT2 reports the condition of the brake.
Status + warning	OUT2 reports, if a warning is pending.
Status + program run	OUT2 indicates, if the module is situated in a program run.

NOTE

Further information and usage options of terminal strip X3 are contained in the configuration tool "Motion Tool Schin (MTS)" ( DVD, document: MotionToolSchunk.pdf). The digital input IN0 cannot be used as external reference switch as long as the gripper is in program mode. The digital input IN0 can only be used with the setting "normal" if the referencing is adjusted on "external switch IN0".

5.4.8 Configuration of terminal strip X4 of the MCS-06 controller

Terminal strip X4 Terminal strip X4 serves for connecting the voltage supply +24 VDC of the power:



Terminal strip X4

Position of terminal strips ([5.4.3, Page 36](#))

Configuration of the pins of terminal strip X4

Pin	Function
1	+24 V power supply
2	GND power supply
3	PE protective conductor


5.4.9 Pin assignment of communication interfaces

The MCS-06 has currently three communication interfaces (RS232, CAN, Profibus DP). The controller can be actuated with the SCHUNK Motion Protocol (SMP) via these interfaces.

- Information on the SMP ([5.4.3, Page 36](#))

All communication interfaces can be connected at the same time, however, only one of them may be active.

Connection RS232 The RS232 is connected via a 9-pin SUB-D plug from the control (PC / SPS) to the controller (MCS-06):



RS232 interface

- Position of the plugs ([5.4.3, Page 36](#))


Due to its properties the communication interface RS232 is not suitable as fieldbus.

- The RS232 interface should only be used as a parameterization interface.

Configuration of the pins for RS232 interface

Pin	Function	Description
1	-	-
2	TxD	Transmit data
3	RxD	Receive data
4	-	-
5	GND	Reference potential for data lines
6	-	-
7	-	-
8	-	-
9	-	-

Connection CAN The CAN is connected via a 9-pin SUB-D bushing from the control (master) to the controller (MCS-06):




CAN interface

Position of the plugs ([5.4.3, Page 36](#))

Configuration of the Pins for CAN interface

Pin	Function	Description
1	-	-
2	CAN-L	CAN BUS signal (dominant low)
3	-	-
4	-	-
5	CAN_SHLD	Optional shielding
6	-	-
7	CAN-H	CAN BUS signal (dominant high)
8	-	-
9	-	-

Connection Profibus DP The Profibus DP is connected via a 9-pin Profibus plug from the control (master) to the controller (MCS-06):




Profibus DP interface

Position of plugs ([5.4.3, Page 36](#))

Configuration of the pins for the Profibus DP interface

Pin	Function	Description
1	-	-
2	-	-
3	RxD/TxD-P	Receive / transmit data plus line (B line)
4	-	-
5	GND	Reference potential for 5V supply voltage
6	+5 V	Supply voltage +5 V DC
7	-	-
8	RxD/TxD-N	Receive / transmit data N line (A line)
9	-	-

5.5 Connecting ground cable



Ground connection

1	Screw	4	Toothed lock washer
2	Plain washer	5	Product
3	Cable lug	6	Ground marking



A ground connection must be established between the product and the machine on the customer's premises.

The ground cable must be mounted to the threaded hole marked by the ground marking. If there is no such threaded hole, mount the ground cable to another free threaded hole of the product.

NOTE

Do not mount the ground cable to a threaded hole that is already mechanically used for something else, e.g. for screwing on accessory. Always mount the ground cable individually.

Always use all components of the screw connection and install them in this order: plain washer, cable lug, and toothed lock washer. See "Ground connection" diagram.

5.6 Function and handling

	NOTICE Possible damage of the gripper, due to insufficient lubrication (dry running) at permanent short strokes. Residues on the toothed belt may lead to blocking of the gripper base jaws. • Observe maintenance intervals. (👉 7, Page 57) • Travel through the entire stroke after every 1,000 cycles or at least once a day.
	NOTICE Danger of collision after recommissioning the controller. • When automatically adjusting the commuting offset, the gripper must be able to perform its full stroke.

NOTE

With the start of the gripping process, the gripping force is acting on the gripper fingers. This force proportionally depends on the current value, meaning: The bigger the current, the bigger the gripping force.


The gripper's servo axis normally moves like on a mechanical stop.

When handling the module, the following must be observed:

- The max. gripping force refers to the loads of the guides. For this reason, it may only be gripped with the maximal admissible current ([👉 3.2, Page 23](#)). It is recommended to position into the workpiece in the positioning mode with speed default and current limitation ("gripping force default"). Due to the cascaded control, the gripper adjusts the current to the set value after the gripper fingers touched the workpiece.

5.7 Commissioning and system integration via the SCHUNK MCS-06 controller

5.7.1 System structure



System structure

Data format The data is transferred in INTEL Format (Little Endian For-mat).

NOTE

The number of connected products depends on the used bus system. A maximum of 255 IDs can be assigned. For more information, see *Motion Control* document.

5.7.2 SCHUNK Motion protocol



SCHUNK Motion protocol

The data frame of the Motion protocol always includes the following elements:

- D-Len (1 Byte)
- Kommando Code (1 Byte)

D-Len (Data Length) specifies the number of subsequent items of user data including the command byte. The data frame consists of one byte, therefore a Motion protocol message can transfer a maximum of 255 data bytes.

The D-Len byte is always followed by the command code, consisting of one byte. If necessary, the command code is followed by the relevant parameters required. If required, a "master command" can be extended with a "sub-command".

All commands sent are immediately confirmed by the module with a response (acknowledge). This response also uses the data frame described above (D-Len, command code, any parameters). If the request has been successfully processed, D-Len always has a value that is not equal to "0x02". If the request failed, D-Len has the value "0x02".

NOTE

To get to know the special features of the different bus systems, see *Motion Tool* document.

5.7.3 Important commands



DANGER

Risk of injury by unexpected movements of the machine/system!

When settings and parameter entries are faulty, components can move in an uncontrolled manner and cause serious injuries.

- Only specialists or specially trained personnel should carry out settings and enter parameters.

NOTE

In all examples only the required parameters are listed, not the optional ones. In the examples "M" stands for Master and "S" for Slave (= product).

NOTE

For further information on the commands, see *Motion Control* document.

Reference run Command code: 0x92

Description: A reference drive is executed.

Parameter: (Master -> Slave): none.

Response (Slave -> Master): "OK" (0x4F4B) if successful. Product is executing the command.

Other: Spontaneous response is possible

Example for REFERENCE

	D-Len	Cmd	Param	Meaning
M -> S	0x01	0x92		
S -> M	0x03	0x92	0x4F0x4B	Successfully referenced

Positioning run **Command code:** 0xB0

Description: Moves the product to a specified position.

Parameter (Master -> Slave):

- Position in configured unit system (must be specified)
- Velocity (optional)
- Acceleration (optional)
- Current (optional)
- Jerk (optional)

Response (Slave -> Master): If possible, the time that the module needs for the movement is returned.

Other: Spontaneous response occurs when position is reached or if positioning run is terminated earlier

Example for MOVE POS

	D-Len	Cmd	Param	Meaning
M -> S	0x05	0xB0	0x00 0x00 0x20 0x41	Move to position 10.0 [mm]
S -> M	0x05	0xB0	0xCD 0xCC 0x04 0x41	Will reach position in 8.3 [sec]

Velocity run **Command code:** 0xB5

Description: A velocity run is executed.

Parameter (Master -> Slave):

- Velocity in the configured unit system (must be specified)
- Current (optional)

Response (Slave -> Master): "OK" (0x4F4B) if successful. Product executes the command.

Other: Spontaneous message is possible if the product is no longer moving.

Example for MOVE VEL

	D-Len	Cmd	Param	Meaning
M -> S	0x05	0xB5	0x9A 0x99 0x31 0x41	Execute velocity run with 11.1 [mm/s]
S -> M	0x05	0xB5	0x4F 0x4B	

Stop the product **Command code:** 0x91

Description: Produkt braked and stopped in the current position.

Parameter(Master -> Slave): None.

Response(Slave -> Master): "OK" (0x4F4B) if successful.

Other: Spontaneous message is possible.

Example for CMD STOP

	D-Len	Cmd	Param	Meaning
M -> S	0x01	0x91		
S -> M	0x03	0xB5	0x4F 0x4B	OK

Stop the product immediately **Command code:** 0x90

Description: Product is stopped as quickly as possible. If a brake is fitted and configured appropriately, it is activated immediately. The motor phases are short-circuited.

Parameters(Master -> Slave): None.

Response (Slave -> Master): Error message "ERROR EMERGENCY STOP" is triggered.

Other: Can only be reset by "CMD ACK."

Example for CMD EMERGENCY STOP

	D-Len	Cmd	Param	Meaning
M -> S	0x01	0x90		
S -> M	0x03	0x88	0xD9	Emergency stop executed

Acknowledge error **Command code:** 0x8B

Description: Acknowledgment of an error message.

Parameter(Master -> Slave): None.

Response (Slave -> Master): „OK“ (0x4F4B)

Others: If all errors have been successfully acknowledged, an "INFO NO ERROR" info message is sent after sending "OK" (0x4F4B).

Example for CMD ACK

	D-Len	Cmd	Param	Meaning
M -> S	0x01	0x8B		
S -> M	0x03	0x8B	0x4F 0x4B	OK

6 Troubleshooting

6.1 Behavior in case of product malfunctions

6.1.1 Gripper does not move

Possible cause	Corrective action
Motor connected incorrectly	Check the connection between motor and controller
Communication not possible	Check bus connection

6.1.2 Gripping force decreases / gripper opens and closes abruptly

Possible cause	Corrective action
Dirt deposits	Clean and, if necessary, lubricate
Dry running of the guide	Lubricate the product, (👉 7, Page 57)

6.1.3 Gripper does not travel through the entire stroke

Possible cause	Corrective action
Dirt deposits between base jaws and guide	Clean and, if necessary, re-lubricate.
Dirt deposits between cover plate and chuck piston	Clean and, if necessary, re-lubricate

6.2 Motor does not turn

Possible cause	Corrective action
Motor lines are defective	Check winding resistances: Motor lines towards each other: $R = 0.4 \dots 2.0 \, \Omega$ (depending on cable length)

6.3 Behavior in case of malfunctions of the MCS-06 SCHUNK controller

6.3.1 LEDs on Controller Do Not Light Up

Possible cause	Corrective action
No voltage connected	Check the power and logic voltage supplies on the controller
Master (control unit) on the field bus is not active	Check the master; reactivate fieldbus communication if necessary

6.3.2 POW LED (Green) Does Not Light Up

Possible cause	Corrective action
No voltage connected	Check power supply on the controller

6.3.3 RDY LED (Green) Does Not Light Up

Possible cause	Corrective action
Incorrect air connections	Check connection
Logic voltage supply missing	Check the logic voltage supply on the controller

6.3.4 ERR LED (Red) Flashing

NOTE

Troubleshooting; see the *Motion Control* document.

6.3.5 Product stops abruptly

If the delivered GSD file has been integrated, the product can report this by means of the **ERROR_CABLE_BREAK (0x76)** parameter.

Possible cause	Corrective action
Bus cable fault (connection interrupted).	Check bus cable for damage and, if necessary, replace it.
	For more troubleshooting, see <i>Motion Control</i> .

6.3.6 Module Does Not Move/Respond

Possible cause	Corrective action
Encoder/Resolver falsch angeschlossen.	Check connection.
Motor connected incorrectly.	Check motor, change if necessary.

7 Maintenance

7.1 Maintenance intervals

Size	EVG 55
Interval [Mio. cycles]	2
Travelling through the entire stroke [cycles]	1,000

Check after every production day or at least once a day if the profiled rail guides of the gripper base jaws are sufficiently lubricated.

7.2 Measures for preserving the gripper's function

The maintenance and lubrication intervals must be adapted to the ambient and operating conditions.

Observe the following factors:

- Extreme operating temperatures
- The effects of condensation
- High vibration loading
- Use in a vacuum
- Very dynamic operation
- Permanent small stroke movements
- Influence of foreign substances (e.g. vapors or acids)

Preserving the gripper's function:

- Do not expose the gripper to drilling emulsion.
- Operate the gripper in an ambient temperature between +5°C and +55°C.
- Observe the bending radii when laying the cable. No torsional movements must occur.
- Since it is a servo system motor, it can generate the indicated forces only for a short term. These forces may overload the gripper and mechanically destroy it. Every overload leads to a decrease of the system's service life.

Do only operate the gripper within the scope of its technical data.

- Gripping force:

The repeat accuracy of the gripping force is $\pm 15\%$. The breakaway torque can vary significantly from gripper to gripper.

If an automatic gripper change shall be enabled, the breakaway torque must be determined during an initialization of the superior control.

For more information on the programming, see control manual.

7.3 Cleaning

7.3.1 Gripper

The module corresponds to IP code 20.

- Clean the module dry, remove all coarse dirt and chips from the cavities of the module.
- Check for damage and, if necessary, replace the module.

Any repair work on the module may only be carried out by SCHUNK.

7.3.2 Controller

The module corresponds to IP code 20.

- Clean the module dry, remove all coarse dirt and chips from the cavities of the module.
- Check for damage and, if necessary, replace the module.


7.4 Lubricants/lubrication points

SCHUNK recommends the lubricants listed.

During maintenance, treat all greased areas with lubricant. Thinly apply lubricant with a lint-free cloth.

Lubrication point	Lubricant
Metallic sliding surfaces	THK AFC-Grease

The lubricant quantity depends on the stroke lengths and stroke cycles.



Lubrication point „S“

1	Profile rail	2	Profile carriage
3	Gripper base jaw		

- 1 Move gripper in „open“ position.
- 2 Apply lubricant at lubrication point „S“ with a brush.
- 3 Distribute the lubricant:
Travel two or three times through the entire stroke.

7.5 Disassembly and assembly



NOTICE

Risk of damage to the product!

Faulty disassembly of the product can cause damage to the mechanics and internal electronics.

- Allow only SCHUNK to disassemble the product.

8 Translation of original declaration of incorporation

in terms of the Directive 2006/42/EG, Annex II, Part 1.B of the European Parliament and of the Council on machinery.

Manufacturer/ SCHUNK GmbH & Co. KG Spann- und Greiftechnik
Distributor Bahnhofstr. 106 – 134
D-74348 Lauffen/Neckar

We hereby declare that on the date of the declaration the following incomplete machine complied with all basic safety and health regulations found in the directive 2006/42/EC of the European Parliament and of the Council on machinery. The declaration is rendered invalid if modifications are made to the product.

Product designation: 2-Finger Parallelgreifer / EVG 55 / elektric
ID number 0306020 ... 0306025, 0306030 ... 0306031

The incomplete machine may not be put into operation until conformity of the machine into which the incomplete machine is to be installed with the provisions of the Machinery Directive (2006/42/EC) is confirmed.

Applied harmonized standards, especially:

DIN EN ISO 12100:2011-03 Safety of machinery - General principles for design -
Risk assessment and risk reduction

The manufacturer agrees to forward on demand the relevant technical documentation for the partly completed machinery in electronic form to national authorities.

The relevant technical documentation according to Annex VII, Part B, belonging to the partly completed machinery, has been created.

Person authorized to compile the technical documentation:
Robert Leuthner, Address: see manufacturer's address

Signature: see original declaration

Lauffen/Neckar, July 2016

p.p. Ralf Winkler,
Head of Gripping Systems
Development