

### 1.4.2 Spare parts packages

Spare parts packages allow for the maintenance and repair of individual components. For information on the range of the spare parts packages, see [www.schunk.com](http://www.schunk.com) > Service.

The following spare parts packages are available for this product:

- Spring spare parts package
- Control cam spare parts package
- Seal kit spare parts package

*ID. No. spare part kit*

| Size    | Spare part kit for           |                 |            |
|---------|------------------------------|-----------------|------------|
|         | "Spring"                     | "Switching cam" | "Seal kit" |
| PGN 50  | 1309013 (IS/-AS)             | -               | 1310017    |
| PGN 64  | 1309951 (AS)<br>1309985 (IS) | 1310004         | 1310019    |
| PGN 80  | 1309986 (AS)<br>1309989 (IS) | 1310007         | 1310020    |
| PGN 100 | 1309990 (AS)<br>1309991 (IS) | 1310008         | 1310024    |
| PGN 125 | 1309992 (AS)<br>1309993 (IS) | 1310009         | 1310027    |
| PGN 160 | 1309995 (AS)<br>1309997 (IS) | 1310010         | 1310029    |
| PGN 200 | 1309998 (AS)<br>1309999 (IS) | 1310013         | 1310031    |
| PGN 300 | 1310001 (IS/-AS)             | 1310014         | 1310033    |
| PGN 380 | 1310002 (AS)<br>1310003 (IS) | 1310015         | 1310034    |